



PURPOSE

To set Otis style D Lock Tubing plug in tubing collar

ASSEMBLY PARTS

1. Fishneck.
2. Core
3. Body
4. Shear Pin Cover
5. Collet

DESCRIPTION

The inner shaft of the running tool must slide up to allow the collet to collapse, at this point the collet is inserted into the Fishneck of the lock and the inner mandrel is slid back down into place and the shear pin is installed.

At this point the tool is ready to be ran into the wellbore and set into a corresponding collar, at desired depth, stop and pull back up until lugs locate in tubing collar, jar down until element is firmly set, pull up and shear off.

PRECAUTIONS

Sand or debris in wellbore may hinder setting operations.

Nominal Size		2.00"	2.50"	3.00"
Assembly Number		0202D200A0	0202D250A0	0202D3000A0
Item	Part Name			
1	Fishneck	0202D20001	0202D25001	0202D30001
2	Mandrel	0202D20002	0202D25002	0202D30002
3	Shear Sub	0202D20003	0202D25003	0202D30003
4	Shear Pin Cover	0202D20004	0202D25004	0202D30004
5	Collet	0202D20005	0202D25005	0202D30005
Upper Thread Connection		0.938"-10 UN	0.938"-10 UN	1.062"-10 UN
Max O.D.		1.375"	1.75"	2.25"
Fishneck Size		1.375"	1.75"	2.31"

* Non-Stock Item. Please call for price and delivery.

When ordering please specify part name and size. Call us Toll Free: 1-800-438-0061