



PURPOSE

Provides a means to release no-go tools and pressure recorders downhole for extended pressure surveys.

ASSEMBLY PARTS

1. Body
2. Pin
3. Set screw

OPERATION

Install the J Unlatching Head into the J Unlatching Tool and lower into the wellbore to desired depth. Set down gently on top of a pre run no-go. The toolstring weight will actuate the J Unlatching Tool and J off of the J Unlatching Head. Remove the toolstring from the wellbore.

Nominal Size		0.75"	1.00"	1.18"
Assembly Number		1201JH075A0	1201JH100A0	1201JH118A0
Item	Part Name			
1	Body	1201JH07501	1201JH10001	1201JH01181
2	Pin	1201JH07502	1201JH10002	1201JH11802
3	Set screw	¼ -20UNC x ½	¼ -20UNC x ½	¼ -20UNC x ½
Lower Thread Connection		0.50"-13 UNC	0.625"-11 UNC	0.75"-16 UNF
Max O.D.		1.00"	1.42"	1.75"
Fishneck size		0.75"	1.00"	1.18"

Nominal Size		1.37"	2.31"
Assembly Number		1201JH137A0	1201JH231A0
Item	Part Name		
1	Body	1201JH13701	1201JH23101
2	Pin	1201JH13702	1201JH23102
3	Set screw	¼ -20UNC x ½	¼ -20UNC x ½
Lower Thread Connection		0.75"-16 UNF	2.375" EUE / 1.062"-10 UN
Max O.D.		1.75"	2.91"
Fishneck size		1.37"	2.31"

When ordering please specify part name and size. Call us Toll Free: 1-800-438-0061