



PURPOSE

To run lock mandrels with equalizing assemblies that require prong mandrels.

DESCRIPTION

The P Running Tool is a simple design, consisting of one part. The tool consists of a single housing with tangential shear pin holes, and a recess to accommodate a prong fishneck.

OPERATION

Pin desire lock (with equalizing assembly) onto running tool, and attach to tool string.

Lower toolstring into wellbore to desired depth above landing nipple. (static and pull weights should be taken at this time)

Lower into landing nipple and jar down to seat no-go / V-packing into landing nipple.

Jar up to shear pins in running tool and remove tool string from wellbore.

Nominal Size	0.875"	1.25" (1.125)	1.50" (1.43, 1.62)
Assembly Number	0202P08701	0101P125001	0101P15001
Top Thread Connection	0.50 - 13 UNC	0.625 - 11 UNC	0.938 - 10 UN
Lower Thread Connection	n/a	0.312" - 18 UNC	0.50" - 13 UNC
Max O.D.	0.812"	1.125"	1.42"
Running Neck Size	0.57"	0.56	1.00"
Fishneck size	0.688"	1.00"	1.18"

Nominal Size	2.00" (1.78)	2.50" (2.18,)	3.00" (2.75, 2.87)
Assembly Number	0202P20001	0202P25001	0202P30001
Top Thread Connection	0.938" - 10 UN	0.938" - 10 UN	1.062" - 10 UN
Lower Thread Connection	n/a	0.50" - 13 UNC	n/a
Max O.D.	1.62"	2.00	2.50
Running Neck Size	1.15"	1.43"	1.93"
Fishneck size	1.375"	1.75"	2.31"

When ordering please specify part name and size. Call us Toll Free: 1-800-438-0061